



INSTALLATION INSTRUCTIONS FOR 120v. WEIGHTED BASE (-WB) BBQ LIGHT FIXTURES

INSPECTED BY:

INSTALLATION FOR BBQ LIGHT FIXTURES:

No installation required.

Plugs into any standard 120v electrical outlet.

IMPORTANT: SAFETY INSTRUCTIONS

This Portable lamp has a grounded plug (three prong) as a feature to reduce the risk of electric shock. This plug will fit in a grounded outlet only one way. If the plug does not fit fully in the outlet contact a qualified electrician. NEVER use with an extension cord unless plug can fully be inserted. DO NOT ALTER PLUG!

CAUTION: Risk of electric shock. Do not use with extension cord near water or where water may accumulate. Keep lamp at least 16 ft. from pools and spas. KEEP PLUG DRY! For use only on GFCI protected units.

WARNING:


Read all instructions when using outdoor portable lamps, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury.

- Use only three-wire extension cords that have a three-prong grounding plug and grounding receptacles that are compatible with appliances plug.
- (GFCI) Ground Fault Circuit Interrupter protection should be provided on the circuit(s) or outlet(s) to be used for the wet location portable lamp. Receptacles are available having built in GFCI protection should be able to be used for this measure of safety.
- Use only with extension cord for outdoor use, such as extension cord of type SW, SW-A, SOW, SOW-A, STW, STW-A, SJW, SJW-A, SJOW, SJOW-AM, SJTW, SJTW-A, or SJTOW, SJTOW-A

LAMP INSTALLATION/REPLACEMENT

1. Turn off power to fixture and unplug from outlet before servicing.
2. Hold body and cap with each hand then rotate and pull on cap to separate.
3. Pull MR16 Bi-Pin lamp away from socket to release.
4. Replace lamp with correct type and wattage marked on fixture label.
5. Re-install cap onto body by rotating cap in circular motion while sliding cap into the body. DO NOT push cap straight into body to prevent O-ring from slipping out of its groove.
6. Plug into any standard 120V electrical outlet, turn on power and check for proper operation.

CAUTION: Do not exceed maximum wattage marked on fixture label.



IMPORTANT SAFETY INSTRUCTIONS TO REDUCE THE RISK OF FIRE AND INJURY TO PERSONS:

1. Light bulb gets hot quickly; turn off, unplug/disconnect and allow to cool down before replacing the light bulb.
2. **DO NOT** touch hot lens, use guard or enclosure.
3. **DO NOT** look into light bulb when on.
4. Keep light bulb away from materials that may burn.
5. Use only with wattage/light bulb marked on fixture warning and instructions.
6. Use the correct light bulb base with the correct socket.
7. **DO NOT** touch light bulb at any time. Use a lint-free cloth when handling the Halogen light bulbs as oil from skin may damage lamp and shorten lamp life.
8. **DO NOT** operate fixture with missing or damaged parts.

For Questions Call 1-888-882-1350